

HYDROFILL-CR

FULLY AUTOMATIC OPEN WELL (SUBMERSIBLE) PUMP STARTER CONTROL PANEL WITH MAGNET SENSOR BASE WATER LEVEL CONTROLLER

Along with all the facility of Water Level Controller like 'Hydrofill' basic model, it has Fully Automatic Starter Control panel for Open Well Submersible Pump kept in the Ground / Under Ground Tank.

Facility to connect Run Capacitor.

Protection against Over Load and Short Circuit using 'ISI MCB'.

While Buying a new Open Well Submersible Pump, no need to buy Starter Panel. Just connect HYDROFILL-CR and get facility of Starter Control Panel along with Fully Automatic Water Level Controller.



HYDROFILL-CRS

FULLY AUTOMATIC SUBMERSIBLE PUMP STARTER CONTROL PANEL WITH MAGNET SENSOR BASE WATER LEVEL CONTROLLER

Along with all the facility of Water Level Controller like 'Hydrofill' basic model, it has Fully Automatic Starter Control Panel for Submersible Pump drilled below deep in to the Ground.

Facility to connect the Start + Run Capacitor with Fully Automatic Run to Start Conversion.

Protection against Over Load and Short Circuit using 'ISI MCB'. Facility of Ampere Meter.

While Buying a new Submersible Pump, no need to buy Starter Panel. Just connect HYDROFILL-CRS and get facility of Starter Con. Panel along with Fully Automatic Water Level Controller.



AUTOLEVEL

SEMI-AUTOMATIC WATER LEVEL CONTROLLER WITH MAGNET SENSOR

Start the Pump Manually & When Tank gets Full, Pump will Stop..... Automatically....



DIGILEVEL FULLY AUTOMATIC WATER LEVEL INDICATOR WITH MAGNET SENSOR

Indicates five levels of the tank. Each level can be indicated in percentage or can be re-calibrated in 'liters' or in 'feet'.

**MOST USEFUL FOR LARGE
TANKS OF TOWNSHIP OR
SOCIETY OR MUNICIPAL
CORPORATION.....**

